

Ceiling Service Panels

Product Description and Characteristics:

The CiF Lab Solutions Ceiling Service Panels are a more economical method of providing connection to gas services, electric and data from the ceiling to your flexible workstation solutions configured below. Ceiling Service Tiles are available in standard sizes of 2-foot x 2-foot and 2-foot x 4-foot tiles, with customized configurations available to meet your project's specific needs.

Finish:

All steel Ceiling Service Tile components shall be finished using a baked-on powder-coat finish. Standard colors include black, grey, light neutral, and white.

Fabrication:

If no gas fixtures are installed at the factory, the hold will have a knock-out present that is removed when a fixture is installed in the field. If no electrical boxes are installed at the factory, there will be a hole cut-out for the box to be installed in the field. If electrical boxes are installed at the factory, they will have a metal duplex box and blank cover installed for field wiring.

Warranty:

All standard products manufactured by CiF Lab Solutions carry a two (2) year guarantee and Limited Warranty from the date of substantial completion to the original owner against defective material and workmanship. Refer to our full warranty for further details.

**24 x 24-Inch (Actual Dimensions are 23 5/8 x 23 5/8-inches) and
24 x 48-Inch (Actual Dimensions are 23 5/8 x 47 5/8-inches)**

