

ColorSplash Wood Casework Options Menu

(Options in Bold are standard)

ColorSplash Guidelines

1. ColorSplash stains can only be applied to straight grain, light colored Reconstituted Veneers
2. Door and Drawer fronts for each cabinet must be the

- same color (except split height tall cabinets)
3. BIM required for CS3 and CS4 projects
4. One cabinet can have up to 3 colors (face, body, and back) up to 13 colors can be used on a single project

5. A set up charge will be applied for each additional color used on a project
6. Please refer to the ColorSplash Color Chart and Possibilities Guide for additional details.

Base Cabinet Construction

- ☐ Full Stretcher Frame
- ☐ Full Sub Top

Intermediate Rails

Intermediate rails always provided when locks are specified.

- ☐ None
- ☐ Between drawers and between drawers over doors

Cabinet Veneer (except components selected for natural veneer for CS 4 only):

- ☐ **Straight-grain, light colored reconstituted veneer**

Natural Veneer (for CS 4 only, cabinet components or fronts that are selected for natural veneer):

- ☐ Red Oak – Plain Sliced
- ☐ Red Oak – Rift cut
- ☐ White Maple – Plain Sliced
- ☐ White Maple – Quarter-cut
- ☐ Other

Green Standard Features

Can help to contribute to specific LEED points, however the total project requirements must be met in order to achieve the desired LEED points. 100% Recycled and recovered content only applies to particle-core plywood.

- ☐ NAUF/FSC
- ☐ Recycled Content to extent possible (particle-core plywood only)

Cabinet Body Substrate

- ☐ Veneer Core

Door and Drawer Substrate

- ☐ Particleboard Core

Unexposed and Concealed Ends

- ☐ **Hardwood veneer with sealer**
- ☐ Same species and finish as exposed ends

Cabinet Base

- ☐ Separate applied veneer-core base
- ☐ Separate applied waterproof plywood base (additional cost)
- ☐ Cabinet end to floor (additional cost)

Base Cabinet Backs

All Lines: Except for CS 4, exposed backs will match the veneer species and cut of the exposed cabinet ends. CS 4 also available with natural veneer backs.

- ☐ **Semi-exposed: White Hardboard**
- ☐ Semi-exposed: straight-grain plywood to match cabinet interior
- ☐ **Unexposed (drawer units): no backs**
- ☐ Unexposed (drawer units): White Hardboard

Also Available for CS 4

Selected components only:

- ☐ Semi-exposed: plywood with natural veneer
- ☐ Exposed: plywood with natural veneer

Wall Cabinet Backs

All Lines: Except for CS 4, exposed backs will match the veneer species and cut of the exposed cabinet ends. CS 4 also available with natural veneer backs.

- ☐ **Semi-exposed: White Hardboard**
- ☐ Semi-exposed: straight-grain plywood to match cabinet interior

Also Available for CS 4

Selected components only:

- ☐ Semi-exposed: plywood with natural veneer
- ☐ Exposed: plywood with natural veneer

Tall Cabinet Backs

All Lines: Except for CS 4, exposed backs will match the veneer species and cut of the exposed cabinet ends. CS 4 also available with natural veneer backs.

- ☐ **Semi-exposed: White low-pressure laminate**
- ☐ Semi-exposed: straight-grain plywood to match cabinet interior

Also Available for CS 4

Selected components only:

- ☐ Semi-exposed: plywood with natural veneer
- ☐ Exposed: plywood with natural veneer

Door and Drawer Front Overlay

Reveals between doors and drawer fronts on the face of the same cabinet will always be 1/8". Two adjacent cabinets will have double the reveal when install side by side.

- ☐ **Full Flush Overlay (1/16" reveal on cabinet end)**

Grain Direction on Doors and Drawer Fronts

- ☐ **Vertically matched grain per cabinet**

Cabinet Edge banding

- ☐ 1/8" (3mm) rolled type banding

Base Cabinet Shelves

- ☐ 3/4-depth shelves (open cabinet shelves will be full depth)

Wall and Tall Cabinet Shelves

- ☐ Full-depth shelves

Drawer Box Construction

- ☐ **Fully dovetailed, 9 ply Baltic Birch, with 1/4" white TFM on MDF core bottoms**
- ☐ Fully dovetailed, 9 ply Baltic Birch, with 1/2" - 9 ply Baltic Birch plywood bottoms

Drawer Slides for Standard Drawers

- ☐ **Full extension, ball bearing, zinc, 100 lb. (DS100)**
- ☐ Full extension, ball bearing, zinc, 150 lb. (DS150)
- ☐ Soft closing, full extension, ball bearing, zinc, 100 lb. (DS300).
 - Not recommended for drawers over 24" wide
- ☐ Soft closing, full extension, ball bearing, zinc, 150 lb. (DS170)
 - Can be used on any drawer but recommended for drawers over 24" wide
- ☐ Other, specify

Drawer Slides for File Drawers

- ☐ Full extension, ball bearing, zinc, 100 lb. (DS100)
- ☐ **Full extension, ball bearing, zinc, 150 lb. (DS150)**
- ☐ Soft closing, full extension, ball bearing, zinc, 150 lb. (DS170)
- ☐ Other, specify

Hinges

Five knuckle hinges will require a door catch. Both three knuckle and concealed hinges have a self-closing mechanism.

- ☐ Heavy duty, five knuckle – painted (HH020)
- ☐ **Heavy duty, five knuckle - brushed chrome (HH040)**
- ☐ Heavy duty, five knuckle - stainless steel (HH010)
- ☐ Medium duty, concealed, 170° opening - nickel plated (HH050)
- ☐ Medium duty, concealed, 110° opening - nickel plated (HH060)
- ☐ Medium duty, three knuckle, 270° opening - nickel plated (HH080)
- ☐ Other, specify

Door Catches

- ☐ **Metal roller catch (RC010)**
- ☐ Magnetic catch (MC010)

Pulls

- ☐ **96 mm wire pull - brushed chrome (DP050)**
- ☐ 96mm wire pull - bright chrome (DP060)
- ☐ 96mm wire pull - stainless steel (DP190)
- ☐ 96mm wire pull – painted (DP170)
- ☐ 4" cast pull – aluminum with flared ends (DP070)
- ☐ Metal flush pull, black (DP120)
- ☐ 4" D pull, aluminum (DP040)
- ☐ Semi-recessed pull, nickel (DP100)
- ☐ Oversized semi-recessed pull (DP110)
- ☐ Other, specify

Shelf Supports

- ☐ Angled Steel Pin (SC220)
- ☐ **Plastic, seismic type (SC240)**

Lock Locations

- ☐ **None**
- ☐ Where indicated or specified
- ☐ File drawers only
- ☐ All drawers
- ☐ All doors
- ☐ All doors and drawers

Lock Type

- ☐ **5 disc cam lock (LK010)**
- ☐ 5 pin cam lock (LK030)
- ☐ 5 pin dead bolt lock (LK040)
- ☐ Other, specify

Keying for Locks

- ☐ Keyed alike
- ☐ Keyed alike per room
- ☐ Keyed differently (Security panels will be provided between drawers)

Tall Door Locks

- (Where indicated or specified)
- ☐ **Same as other locks**
 - ☐ 3-point locking handle (LK050)
 - ☐ Other, specify

Padlock Hasps

- (Where indicated or specified)
- ☐ **Cam-type padlock-able hasp, Olympus DCN (PH010)**
 - ☐ Padlock loop and guard plate (PH020)

Glass for Glazed Doors

- ☐ **Tempered**
- ☐ Laminated Safety

Label Holders

- ☐ **None**
- ☐ File drawer only
- ☐ All drawers (including file drawers)
- ☐ All drawers and doors (double doors will receive one)

Number Plate Locations

Shipped loose for field installation

- ☐ **None**
- ☐ Where indicated or specified
- ☐ File drawers only
- ☐ All drawers
- ☐ All doors (double doors will receive one)
- ☐ All doors and drawers (double doors will receive one)
- ☐ Where there are Padlock hasps